


NV9 USB+

Standard Options

NV9-USB 101

Cash Box
300 Slide In (PA00192)


Bezel
Horizontal (PA00189)



NV9-USB 102

Cash Box
600 Slide In (PA00194)

Bezel
Horizontal (PA00189)




NV9-USB 501

Cash Box
300 Lockable (PA00186)

Bezel
Horizontal (PA00189)


Configurations
Front Right / Back Right
Front Left / Back Left



NV9-USB 601

Cash Box
300 Slide In (PA00192)


Bezel
Horizontal Rainbow (PA01144)



NV9-USB 701

Cash Box
600 Slide In (PA00194)

Bezel
Horizontal Rainbow (PA01144)




NV9-USB 102

Cash Box
300 Slide In (PA00192)

Bezel
Vertical Down Snout (PA00191)


Also Available:
Cash Box
600 Slide In (PA00194) | NV9 USB-202



NV9-USB 302

Cash Box
300 Clip On (PA00185)

Bezel
Vertical Down Snout (PA00191)



NV9-USB 402

Cash Box
600 Clip On (PA00185)

Bezel
Vertical Down Snout (PA00191)



NV9 USB+

Standard Options

NV9-USB 103

Cash Box

300 Slide In (PA00192)

Bezel

Vertical Up (PA00188)

Also Available:

Cash Box

600 Slide In (PA00194) | NV9 USB-203



NV9-USB 303

Cash Box

300 Clip On (PA00185)

Bezel

Vertical Up (PA00188)



NV9-USB 403

Cash Box

600 Clip On (PA00193)

Bezel

Vertical Up (PA00188)



NV9-USB 603

Cash Box

300 Clip On (PA00185)


Bezel

Vertical Rainbow (PA02388)

Also Available:

Bezel

Vertical Rainbow 69mm (PA02383)



NV9-USB 703

Cash Box

600 Clip On (PA00193)


Bezel

Vertical Rainbow (PA02388)

Also Available:

Bezel

Vertical Rainbow 69mm (PA02383)



NV9-USB 104

Cash Box

300 Slide In (PA00192)


Bezel

Vertical Up Snout (PA00190)

Also Available:

Cash Box

600 Slide In (PA00194) | NV9 USB-204




NV9-USB 304

Cash Box

300 Clip On (PA00185)

Bezel

Vertical Up Snout (PA00190)



NV9-USB 404

Cash Box

600 Clip On (PA00193)

Bezel

Vertical Up Snout (PA00190)

